

Use **Liquid Defoamer** with extraction cleaning carpets that have been shampooed, foam cleaned, or bonnet-maintained excessively, to help eliminate foam build-up left in carpeting from excess cleaning detergents. **Liquid Defoamer** is easily dispersed in hot or cold water, and can be lightly sprayed on the carpet before cleaning, or added to the recovery tank.

Liquid Defoamer will help protect extraction vacuum motors by reducing excessive foam to liquid more quickly.

Key Features of Liquid Defoamer

- · Eliminates foam build-up from previous cleaning
- Saves labor and time





P: 800.942.9199 F: 216.279.0019 www.hospecobrands.com





Liquid Defoamer Treatment



Quart 6/case Gallon 4/case C276-009 C276-005 **Liquid Defoamer Treatment**

Also available in 55 gallon drum Diluted pH 6.5-7

DIRECTIONS: Shake well before using.

Test fabric in inconspicuous place for color fastness before using.

Dilute 1 part Defoamer to 7 parts water (4 oz. Defoamer plus water to 1 quart). Should be prepared, carried and used by your cleaning crew.

IN THE VACUUM TANK:

Defoamer is best used in the vacuum tank. Start with 1 oz. (30 mL) of diluted Defoamer for a 5 gallon tank. More may be added as needed. Properly used Defoamer adds dimensions to your vacuum tank to permit full use of the extraction process.

IN THE CLEANING SOLUTION:

When the carpet has heavy shampoo residue, diluted Defoamer may also be added to the cleaning solution. Try 1 oz. (30 mL) per 5 gallon (18.9 L) of solution. **Note:** Defoamer in the solution tank might cause clogging of some equipment filters.

AS A SPRAY:

When the carpet has a heavy shampoo residue, diluted Defoamer may also be sprayed on the carpet before cleaning. Mix 1 oz. (30 mL) of diluted Defoamer and dilute that further with water to 1 quart (946 mL) . Spray this very sparingly to cover at least 200 square feet.

NOTE: Freezing will not affect cleaning power. Thaw, shake well and use.













